



Cisco IP Phone 6851 Series User Guide

Chapter 1 - The Cisco 6851 Phone	Page 2
Chapter 2 – Calls	Page 14
Chapter 3 – Contacts	Page 29
Chapter 4 – Recent Calls	Page 31
Chapter 5 – Voicemail	Page 34
Chapter 6 – Settings	Page 36

540 Delaware Ave., PO Box 197, Palmerton, PA 18017
1.800.281.3564 | www.penteledata.net | www.ptd.net

CHAPTER 1

The Cisco 6851 Phone

The Cisco IP Phone 6851 Phone deliver easy-to-use, highly-secure voice communications.

Figure 1: Cisco IP Phone 6851 Phone



Table 1: Cisco IP Phone 6851 Phone Major Features

Features	6851
Screen	Greyscale, with backlight
Lines	4
Fixed feature keys	9
Power over Ethernet (PoE)	Supported
Electronic Hookswitch Headset support	Supported


When you add features to your phone, some features require a line button. But each line button on your phone can support only one function (a line, a speed dial, or a feature). If your phone's line buttons are already in use, your phone won't display any additional features.

Phone Setup

Typically, your administrator sets up your phone and connects it to the network. If your phone is not set up and connected, contact your administrator for instructions.

Adjust the Handset Rest

If your phone is wall-mounted or if the handset slips out of the cradle too easily, you may need to adjust the handset rest to ensure that the receiver does not slip out of the cradle.



Procedure

-
- Step 1** Remove the handset from the cradle and pull the plastic tab from the handset rest.
 - Step 2** Rotate the tab 180 degrees.
 - Step 3** Hold the tab between two fingers, with the corner notches facing you.
 - Step 4** Line up the tab with the slot in the cradle and press the tab evenly into the slot. An extension protrudes from the top of the rotated tab.
 - Step 5** Return the handset to the handset rest.
-

Connect to the Network

You need to connect the phone to the telephone network.

- Wired connection—the phone is plugged into the network using an Ethernet cable.

Buttons and Hardware


Figure 2: Cisco IP Phone 6851 Series Buttons and Features



1	Handset and Handset light strip	Indicates whether you have an incoming call (flashing red) or a new voice message (steady red).
2	Programmable feature buttons and line buttons	Access your phone lines, features, and call sessions.
3	Softkey buttons	Access functions and services.
4	Navigation cluster	Navigation ring and Select button. Scroll through menus, highlight items, and select the highlighted item.
5	Hold/Resume, Conference, and Transfer	Hold/Resume - Place an active call on hold and resume the held call. Conference - Create a conference call. Transfer - Transfer a call.
6	Speakerphone, Mute, and Headset	Speakerphone - Toggle the speakerphone on or off. When the speakerphone is on, the button is lit. Mute - Toggle the microphone on or off. When the microphone is muted, the button is lit. Headset - Toggle the headset on or off. When the headset is on, the button is lit.
7	Contacts, Applications, and Messages	Contacts - Access personal and corporate directories. Applications - Access call history, user preferences, phone settings, and phone model information. Messages - Autodial your voice messaging system.
8	Volume button	Adjust the handset, headset, and speakerphone volume (off hook) and the ringer volume (on hook).

Navigation

Use the outer ring of the Navigation cluster to scroll through menus and between lines. Use the inner **Select** button of the Navigation cluster to select items.









If a menu item has an index number, you can enter the index number with the keypad to select the item.

Softkey, Line, and Feature Buttons

- You can interact with the features on your phone in several ways:
- Softkeys, located below the screen, give you access to the function displayed on the screen above the softkey. The softkeys change depending on what you are doing at the time. The $\square\square\square$ and $\square\square\square$ softkey indicate more softkey functions are available.
- Feature and line buttons, located on either side of the screen, give you access to phone features and phone lines.
 - Feature buttons—Used for features such as **Speed dial** or **Call pickup**, and to view your status on another line.
 - Line buttons—Used to initiate or answer a call or resume a held call. You can also use a line key to open and close the call session window, and to navigate through the call session window. Open the call session window to see the calls on the line.

Feature and line buttons illuminate to indicate status:

-  - Green, steady: Line ready
-  - Amber, steady: Line not registered
-  - Amber, flashing: Line registering
-  - Red, steady: Line in use
-  - Red, flashing: Incoming call
-  - Red, Pulsing: Line on hold

Your administrator can set up some functions as softkeys or as feature buttons. You can also access some functions with softkeys or the associated hard button.

Phone Screen Features

The phone screen shows information about your phone such as directory number, active call and line status, softkeys, speed dials, placed calls, and phone menu listings. The screen is made up of three sections: the header row, the middle section, and the footer row.

Figure 3: Cisco IP Phone 6851 Screen



1	At the top of the screen is the header row. The header row displays the current date and time, as well a number of icons. The icons display when features are active.
2	<p>The middle of the phone screen displays the information associated with the line and feature buttons on the phone.</p> <p>When you select a line which has more than two registered lines, a black box highlight around the selected line is displayed. There will be no highlight for an active call.</p> <p>Active and incoming call screen supports more than 21 characters. The Cisco IP Phone can display 15 digits on the phone screen when line is inactive.</p>
3	The bottom row of the screen contains the softkey labels. Each label indicates the action for the softkey button below the screen.

Clean the Phone Screen

Procedure

If your phone screen gets dirty, wipe it with a soft, dry cloth.

Caution: Do not use any liquids or powders on the phone because they can contaminate the phone components and cause failures.

Accessibility Features

The Cisco IP Phone 6800 Series Multiplatform Phones provide accessibility features for the blind, and the visually, hearing, and mobility impaired. Because many of these features are standard, they can be used by users with disabilities without requiring any special configuration.

Hearing-Impaired Accessibility Features

Your phone comes with standard accessibility features that require little or no setup.

Figure 4: Hearing-Impaired Accessibility Features









1	Visual message-waiting indicator (handset)	This lighted strip is visible from all angles. Your phone also provides an audible message-waiting indicator.
2	Visual notification of the phone state	<ul style="list-style-type: none"> • Toggle the Mute and Speakerphone buttons on and off to indicate the phone state. • Use the Mute button to toggle the microphone on or off. When the microphone is muted, the button is lit. • Use the Speakerphone button to toggle the speakerphone on or off. When the speakerphone is on, the button is lit.
3	Inline-amplifier support (handset)	Cisco IP Phone handsets support third-party inline amplifiers. You attach an amplifier to the handset and cord and it sits between the handset and the IP phone.
4	Adjustable ringtone, pitch, and volume	<ul style="list-style-type: none"> • Select Applications > User preferences. • Adjust the volume level for the phone ring. While the handset is in the cradle and the headset and speakerphone buttons are off, press Volume to raise or lower the volume. Your administrator can also change your settings.
5	Hearing aid compatible (HAC) handset	Supports these accessibility features: <ul style="list-style-type: none"> • Hearing-aid compatible. • Magnetic coupling of the hearing aid. • Federal Communications Commission (FCC) loudness requirements for the Americans with Disabilities Act (ADA). • Section 508 loudness requirements, which are met by using industry-standard inline handset amplifiers.
6	Acoustic coupled TTY and TDD support (handset)	<p>Cisco IP Phones support these TTY and TDD features:</p> <ul style="list-style-type: none"> • Acoustic or direct connect TTYs from industry-leading manufacturers. • Real-time text transmission over phone lines. • Hearing and voice carry over phones (HCO/VCO). • VoIP network operating at G.711. <p>For information about setting up TTY, contact your administrator.</p>

Vision-Impaired and Blind Accessibility Features

Your phone comes with standard accessibility features that require little or no setup.

Figure 5: Vision-Impaired and Blind Accessibility Features



1	High-contrast visual and audible alert of an incoming call	Alerts you to an incoming call. The handset light strip flashes during incoming calls and stays lit when a voicemail message is received.
2	Line and feature buttons on the Cisco IP Phone The line and feature buttons are on the left and right sides of the screen.	Use line buttons to start, answer, or switch to a call on a particular line. Features, such as speed dial, line status, privacy, do not disturb (DND), and service URLs, can be assigned to feature buttons. Your administrator sets up programmable feature buttons on your phone. Colors indicate your phone's status:  - Green, steady: Line ready  - Amber, steady: Line not registered  - Amber, flashing: Line registering  - Red, steady: Line in use  - Red, flashing: Incoming call  - Red, Pulsing: Line on hold
3	Back-lit grayscale LCD screen with adjustable contrast on the Cisco IP Phone	Allows you to adjust your phone screen's contrast.
4	Softkeys • These are large buttons just below the LCD.	Provide access to special functions. The functions are displayed on the LCD.
5	Navigation Cluster (includes the Navigation ring and the Select button) • The Navigation cluster is located in the center of the phone.	Use the Navigation ring to move up and down in the phone LCD. The Select button is in the center of the Navigation cluster.







6	<p>Hold button, Transfer button, and Conference button</p> <ul style="list-style-type: none"> • These three large buttons are located to the right of Navigation cluster. • In this group of buttons, the Hold button is the single button in the top row. Below the Hold button, the Transfer button is on the left, and the Conference button is on the right. 	Allow you to use these functions on your phone.
7	<p>Messages button, Applications button, and Contacts button</p> <ul style="list-style-type: none"> • These three large buttons are located to the left of the Navigation cluster. • In this group of buttons, the Messages button is the single button in the top row. Below the Messages button, the Applications button is on the left, and the Contacts button is on the right. 	Allow you to easily access your messages, applications, and contacts.
8	<p>Volume key</p> <ul style="list-style-type: none"> • This key is located to the left of the keypad. 	<p>Allows you to increase or decrease the ring volume or the sound through the handset, headset, or speakerphone.</p> <p>Press up on the rocker key to increase the volume. Press down on the rocker key to decrease the volume.</p>
9	Standard 12-key layout	Allows you to use existing or familiar key positions. Key 5 has a nib.
10	<ul style="list-style-type: none"> • Headset, Speakerphone, and Mute buttons located to the right of the keypad. • The Speakerphone button is on the top, the Headset button is in the middle, and the Mute button is on the bottom. 	<p>Provide audible notification of the phone state:</p> <ul style="list-style-type: none"> • Toggle the Headset, Mute, and Speakerphone buttons on and off to indicate the phone state. • Use the Headset button to toggle the headset on or off. When the headset is on, the button is lit. • Use the Mute button to toggle the microphone on or off. When the microphone is muted, the button is lit. When you turn on Mute, your phone beeps once; when you turn off Mute, your phone beeps twice. • Use the Speakerphone button to toggle the speakerphone on or off. When the speakerphone is on, the button is lit.

Mobility-Impaired Accessibility Features

Your phone comes with standard accessibility features that require little or no setup.

Figure 6: Mobility-Impaired Accessibility Features



1	Lighted buttons	<p>Allow you to access the following features:</p> <ul style="list-style-type: none"> • Phone lines and intercom lines (line buttons) • Speed-dial numbers (speed-dial buttons, including the speed-dial line status feature) • Web-based services, such as a personal address book • Phone features, such as privacy <p>Indicate your phone's status:</p> <ul style="list-style-type: none">  - Green, steady: Line ready  - Amber, steady: Line not registered  - Amber, flashing: Line registering  - Red, steady: Line in use  - Red, flashing: Incoming call  - Red, Pulsing: Line on hold
2	Large buttons to access Applications, Messages, Contacts, Hold, Transfer, and Conference	Allow you to easily access your phone applications, voice messages, corporate and personal directories, and calling features.
3	Built-in speakerphone	Indicates whether the speakerphone is on or off. When the speakerphone is on, the button is lit.
4	Tactile-discernible buttons and functions, including a nib on Key 5	Allow you to easily locate your phone's keys. For example, Key 5 has a nib, which you can use to locate other key positions.

Monitor a Coworker's Line - Busy Lamp Field

With the busy lamp field feature, you can monitor the line status of a coworker or supervisor. This feature is useful if you routinely handle calls for a colleague and need to see their ability to answer a call.




If this feature is configured on your phone, the following LED colors display on a line key:

- A green LED - Monitored line is available.
- A red LED - Monitored line is busy.
- A red fast blinking LED - A call is ringing to the monitored line.
- An amber LED - A configuration error occurred when this feature was being set up.

On your phone, you see the caller ID for the calls that you receive. For lines that you monitor, you do not see caller ID.

You can use this feature with speed dial or call pickup for even greater flexibility. You may see different icons displayed on your phone based on your combination of features. The following table shows the various busy lamp field icons based on each feature combination.

Table 2: Busy Lamp Field Icons

	Idle	Alerting	In use	Error
Busy Lamp Field, Speed Dial, and Call Pickup				

Find Information about Your Phone

Your administrator may ask for information about your phone. This information uniquely identifies the phone for troubleshooting purposes.

Procedure

Step 1 Press **Applications** .

Step 2 Select **Status > Product Information**.

You can view the following information:

Product name - Model number of the Cisco IP Phone.

Serial number - Serial number of the Cisco IP Phone.

MAC address - Hardware address of the Cisco IP Phone.

Software version - Version number of the Cisco IP Phone firmware.

Hardware version - Version number of the Cisco IP Phone hardware.

Certificate - Status of the client certificate, which authenticates the Cisco IP Phone for use in the ITSP network. This field indicates if the client certificate is properly installed in the phone.

Customization - For an RC unit, this field indicates whether the unit has been customized or not.

Pending indicates a new RC unit that is ready for provisioning. If the unit has already retrieved its customized profile, this field displays the Customization state as Acquired.

Step 3 Press **Back** to return to the Applications screen.

View the Network Status

Procedure

Step 1 Press **Applications** .

Step 2 Select **Status > Network Status**.

You can view the following information:

- **Network type** - Indicates the type of Local Area Network (LAN) connection that the phone uses.
- **Network status** - Indicates if the phone is connected to a network.
- **IPv4** - IP address of the phone. You can see information on IP address, VLAN ID, Addressing type, IP status, Subnet mask, Default router, Domain Name Server (DNS) 1, DNS 2 of the phone.
- **IPv6** - IP address of the phone. You can see information on IP address, VLAN ID, Addressing type, IP status, Subnet mask, Default router, Domain Name Server (DNS) 1, DNS 2 of the phone.
- **MAC address** - Unique Media Access Control (MAC) address of the phone.
- **Host name** - Displays the current host name assigned to the phone.
- **Domain** - Displays the network domain name of the phone. Default: cisco.com
- **Switch port link** - Status of the switch port.
- **Switch port config** - Indicates speed and duplex of the network port.
- **PC port config** - Indicates speed and duplex of the PC port.
- **PC port link** - Indicates speed and duplex of the PC port.

View the Phone Status

Procedure

Step 1 Press **Applications** .

Step 2 Select **Status > Phone Status > Phone Status**.

You can view the following information:

- **Elapsed time** - Total time elapsed since the last reboot of the system
- **Tx (Packets)** - Transmitted packets from the phone.
- **Rx (Packets)** - Received packets from the phone.

View the Status Messages on the Phone

Procedure

Step 1 Press **Applications** .

Step 2 Select **Status > Status messages**.

You can view a log of the various phone statuses since provisioning was last done.

Note: *Status messages reflect UTC time and are not affected by the time zone settings on the phone.*

Step 3 Press **Back**.

View the Line Status

Procedure

Step 1 Press **Applications** .

Step 2 Select **Status > Phone status > Line status**.

You can view the status of each line on the phone.

View the Transaction Status

Procedure

Step 1 Press **Applications** .

Step 2 Select **Network configuration > Ethernet configuration > 802.1X authentication > Transaction status**.

You can view the following information:

- **Transaction status**
 - **Protocol**
-

View the Reboot History

Procedure

Step 1 Press **Applications** .

Step 2 Select **Status > Reboot history**.

You can view the details of the date and time whenever the phone has rebooted, no matter why the phone rebooted.

CHAPTER 2

Calls

Make a Call

Use your phone just like any other phone to make a call.

Procedure

Enter a number and pick up the handset.

Make a Call with the Speakerphone

Use your speakerphone for hands-free calling. Keep in mind that your coworkers might be able to hear your call too.

Procedure

Step 1 Enter a number using the keypad.

Step 2 Press **Speakerphone** .

Make a Call with a Headset

Use your headset for hands-free calling that won't disturb your coworker and gives you some privacy.

Procedure

Step 1 Plug in a headset.

Step 2 Enter a number using the keypad.

Step 3 Press **Headset** .

Redial a Number

You can call the most recently dialed phone number.

Procedure

Step 1 (Optional) Select a line.

Step 2 Press **Redial**.

Make an Emergency Call

Use your phone to make an emergency call, similar to any other call. When you dial the emergency number, your emergency services get your phone number and location so that they can assist you.



Note: *If your call disconnects, the emergency services can call you back.*

Before you begin

Your phone must be set up to obtain your physical location. Emergency services personnel need your location to find you when you make an emergency call.

Procedure

Enter the emergency number and lift the handset.

Caller ID

Outbound Caller ID

The caller ID number sent with outbound calls is set on each user. Users can send out the main company number, a specific user-assigned number, or not send out any caller ID.

Note: Calls to 911 ignore the caller ID settings of the user and send the 911 callback number set on the device.

Internal Caller ID

When calling another user on your PBX, the user's extension with their name is the caller ID.

Caller ID Block per Call

Prevents your caller ID (name and number), from being displayed to the next person you call.

Procedure

Step 1 Lift the receiver.

Step 2 Dial ***67** and Dial the number of the party you're trying to reach.

- Your caller ID will not be displayed to the party you called.
 - Your caller ID will be displayed on future calls.
-

Unblock Caller ID per Call

To allow your caller ID to be sent to the person you dial:

Procedure

Step 1 Lift the receiver.

Step 2 Dial ***65** and Dial the number of the party you're trying to reach.

- Your caller ID will be displayed to the party you called.
 - Your caller ID will **not** be displayed on future calls.
-


Speed Dial

Speed Dial allows you to press a button, enter a preset code, or select a phone screen item to place a call. You can configure the speed dial from the phone screen and also from the phone web page. You can edit, delete, and validate a speed-dial code.

Assign a Speed-Dial Code from the Phone Screen

You can configure a speed-dial index from your phone screen.

Procedure

-
- Step 1** Press **Applications** .
 - Step 2** Select **Speed dial**.
 - Step 3** Scroll to an unassigned speed-dial index.
 - Step 4** Press **Edit** and do one of the following:
 - Enter the name and number.
 - Select **Option** > **Select from contact** to select a contact from the address book.
 - Step 5** Select **Save**
-

Make a Call with a Speed-Dial Code

Before you begin

Set up speed-dial codes from your phone's **Applications** menu. (Above)

Procedure

Enter the speed-dial code and press **Call**.

Configure a Speed Dial on a Line Key

You can press any idle line key on your phone and set up speed dial on it. The speed-dial icon, the name, and the extension number are displayed on your phone screen next to the line key. You can also verify this change by checking the **Extended Function** field on the web page. After you configure the speed dial on a line key, you can press the line key to modify the speed-dial information and assign a new phone number and name. You can press the line key that has speed-dial configured to speed dial a number.

You can configure your key expansion module line key as a speed dial key, and you can press that line key to speed dial a number.

Procedure

-
- Step 1** Press any idle line key on your phone for at least two seconds.
 - Step 2** In the **Speed-Dial** window, add the speed-dial name and phone number to call when you press this line key.
 - Step 3** Click **Save**.
-

Remove a Speed Dial from a Line Key

You can press a line key on your phone and delete speed dial assigned to it. The speed dial on the line key is removed. Check the phone web page to confirm that the speed dial is removed.

Procedure

-
- Step 1** Press a line key that has a speed dial configured for at least two seconds.
 - Step 2** Press **Option** > **Delete** in the **Speed-Dial** window on the phone screen.
-

Line Monitoring/BLF/Call Pickup

Working closely with other members of your team sometimes involves answering their phones. Line Monitoring, or Busy Lamp Field (BLF), allows you to set one of your unused phone lines to monitor the status of another user. This functions as a speed dial and can be used to answer a call ringing on another person's phone, or to see if your team member is currently on the phone or not.

Note: These buttons must be configured in the voice web portal by your administrator. The BLF/Presence button does not provide ringing or Caller ID.

Shared Lines

When a team wants to work together to answer the same calls, this simple method allows multiple phones to share the same extension. All calls ringing to the assigned extension will ring any of the phones sharing this line. When receiving a call, the IP Phone display will show which extension is ringing.

Note: Users can also place an outbound call from their normal extension or choose from any shared extensions they have configured.

Note: These buttons must be configured in the voice web portal by an administrator.

Social and Public Services

The following services are available using a short code through your phone service.

211 – Community Services Assistance

Access to information about health and human services by dialing “211” (United States).

411 – Directory Assistance

Nationwide U.S. Directory Assistance can be reached by dialing “411”.

611 – Call PenTeleData Customer Service

Specially set up short code for you to be able to contact our customer service team.

711 – Telecommunications Relay Service

Telecommunications Relay Service (TRS) can be accessed by dialing “711” (United States and Canada).

811 – Local Utilities “Call Before You Dig”

Each state has its own 811 call center to help you get digging. An 811 representative will take information about your project and notify appropriate utility companies to mark buried lines, so you can dig safely around them.

911 - Emergency Services

When you dial “911”, your call is connected to a local 911 operator in the nearest Public Safety Answering Point (PSAP) based on your address.

Note: The 911 operator is sent the callback number and address for that number.

Answer Calls

Your Cisco IP Phone works just like a regular phone. But we make it easier for you to answer calls.

Answer a Call

Procedure

Press the flashing red session button. If you have multiple lines on your phone, press the solid red line button first.

Call Waiting

When you're on an active call, you know that a call is waiting when you hear a single beep and the session button flashes red.

Procedure

Step 1 (Optional) If you have more than one call waiting, select an incoming call.

Step 2 Press the line button.

Temporarily Disable Call Waiting – One Call

Keep the next phone call you make from being interrupted.

Procedure

Step 1 Lift the receiver.

Step 2 Dial *70 and Dial the number of the party you want to reach.

- Call Waiting is disabled for the current call.

Step 3 After you hang up, Call Waiting will be active again.

Enable/Disable Call Waiting – All Calls

Enable or Disable Call Waiting on all future calls.

Procedure

Enable

Step 1 Dial *43.

- Message will play, "Your call waiting service has been activated".

Disable

Step 1 Dial *44 .

- Message will play, "Your call waiting service has been deactivated".
-

Decline a Call

You can send an active or ringing call to your voicemail system or to a preset phone number.

Procedure

Decline a call by performing one of the following actions:

- Press **Decline**.
- If you have multiple incoming calls, highlight the incoming call and press **Decline**.

Do Not Disturb

You can turn on or off the do not disturb feature by dialing the respective star codes that are configured.

Application Menu Procedure

Step 1 Press **Applications** .

Step 2 Select **User preferences > Call preferences > Do not disturb**.

Step 3 Press **On** to turn on DND or press **Off** to turn off DND.

Step 4 Press to exit.

Softkey Procedure

Step 1 Press More  softkey

Step 2 Press DND softkey to turn ON, Press Clr DND to turn OFF.

* Code Procedure

Step 1 To turn on DND, dial *78.

Step 2 To turn off DND, dial *79.

Answer a Coworker's Phone (Call Pickup)

If you share call handling tasks with your coworkers, you can answer a call that is ringing on a coworker's phone.

Answer a Call Within Your Group (Call Pickup Group)

You can answer a call that rings on another phone within your call pickup group. If multiple calls are available for pickup, you'll answer the call that has been ringing for the longest time. First, your administrator must assign you to at least one call pickup group.

Call Pickup Group Procedure

Step 1 When you hear another extension ringing in your group, pick up the handset, and dial *81.

Answer a Call to another extension Directly

You can answer a call that rings on another phone.

Call Pickup Group Procedure

Step 1 When you hear another extension ringing, pick up the handset, and dial **extension.

Call Screening

You have control to ensure you receive important calls. You can limit the callers that ring your phone, filter callers, or forward important callers to another number. Calls from anonymous callers, or other callers, can be given special treatment: either being blocked, sent directly to voicemail, forwarded to another phone number (like your mobile), or having a custom ring pattern assigned.

Anonymous Call Block

Calls from anonymous callers or phones not sending a caller ID, can waste your time and distract you from other calls you want to take. These calls can be filtered from even ringing your phone. You can choose to have anonymous callers either hear a busy signal or a message informing them that you are not accepting calls from anonymous callers.

Enable/Disable Anonymous Call Block

Anonymous caller will hear a busy tone.

Procedure

Step 1 Dial *77 to enable Anonymous Call Block.

- You will hear a prompt saying, “Your anonymous call rejection service has been activated. All incoming calls will be checked for number privacy before they are allowed to complete to your line”.

Step 2 Dial *85 to disable Anonymous Call Block.

- You will hear a prompt saying, “Your anonymous call rejection service has been deactivated”.
-

Enable/Disable Anonymous Call Block with Message

Anonymous caller will hear a message indicating anonymous callers are not allowed.

Procedure

Step 1 Dial *95 to enable Anonymous Call Block with Message.

- You will hear a prompt saying, “Your anonymous call rejection service has been activated. All incoming calls will be checked for number privacy before they are allowed to complete to your line”.

Step 2 Dial *85 to disable Anonymous Call Block with Message.

- You will hear a prompt saying, “Your anonymous call rejection service has been deactivated”.
-

Call Screening – All Callers

If you don't want to receive calls from anyone, you can use this feature and then enable only specific callers to reach you (see Allow Custom Caller).

Procedure

Step 1 Dial *64 to enable All Other Callers Block.

- You will hear a prompt saying, “Your selective call accept service has been activated”.

Step 2 Dial *74 to disable All Other Callers Block.

- This will allow calls from everyone NOT specifically blocked.
 - You will hear a prompt saying, “Your selective call accept service has been deactivated”.
-

Call Screening – Custom Number

If you want to screen calls from a specific number, you can use the Custom Call Screening feature to control who can call your phone and what happens when they do. This can be done via the online voice portal or star code.

Allow Custom Caller

If you have blocked all callers and want to allow a specific caller to contact you, use this feature.

Procedure

Step 1 Dial *59

Step 2 Enter your voicemail **PIN** followed by **#**.

Step 3 Enter the **number** to be blocked followed by **#**.

- You will hear a prompt saying, "Calls from [phone number you entered] will be allowed".
-

Block Custom Caller

If you have allowed all callers and want to block a specific caller, use this feature. The caller will hear a busy signal instead of reaching you.

Procedure

Step 1 Dial *60

Step 2 Enter your voicemail **PIN** followed by **#**.

Step 3 Enter the **number** to be blocked followed by **#**.

- Be sure to include "1" before the 10-digit phone number.
 - You will hear a prompt saying, "Calls from [phone number you entered] will be blocked".
-

Block Custom Caller with Message

The caller will hear a message indicating that calls are not being accepted at this time.

Procedure

Step 1 Dial *58

Step 2 Enter your voicemail **PIN** followed by **#**.

Step 3 Enter the **number** to be blocked followed by **#**.

- Be sure to include "1" before the 10-digit phone number.
- You will hear a prompt saying, "Calls from [phone number you entered] will be blocked".

Note: The message the caller will hear is "The number you have dialed is not accepting calls at this time. Please try again later."

Mute Your Call

While you are on a call, you can mute the audio so that you can hear the other person, but they cannot hear you.


Procedure

Step 1 Press **Mute** .

Step 2 Press **Mute** again to turn mute off.

Put a Call on Hold

Procedure

Step 1 Press **Hold** .

Step 2 To resume a call from hold, press **Hold** again.

Swap Between Active and Held Calls

You can easily switch between active and held calls.

Procedure

Press the line button for the held call, then press **Resume** to resume that call and place the other call on hold automatically.

Call Park

You can use your phone to park a call. You can then retrieve the call either from your phone or another phone, such as a phone at a coworker's desk or in a conference room.

A parked call is monitored by your network, so you won't forget about it. If the call remains parked for too long, you hear an alert. You can then answer, decline to answer, or ignore the call on your original phone. You can also continue retrieving it from another phone.

If you don't answer the call within a certain length of time, it's routed to voicemail or another destination, as set by your administrator.

Use Call Park via Assigned Line on IP Phone

When you have a parking spot assigned to a line on your phone, you can send calls there and retrieve them at the click of a button.

Note: Please contact PenTeleData to set up the parking spots. Once created, the parking spots can be assigned to your IP phone via the online voice portal.

Park a Call

Procedure

Step 1 While on a call, press the button assigned to the parking spot.

Step 2 The call will be placed in that parking spot.

Retrieve a Parked Call

Procedure



Step 1 Press the button on the phone with the assigned parking spot the call has been placed in.

Step 2 You will be connected with the parked caller.

Use Call Park via Star Code

If you do not want to use a line on your phone as a reserved parking spot, you can still park calls via the Call Park and Call Park Retrieval star codes.

Procedure

-
- Step 1** While on a call, Press **Transfer** .
 - Step 2** **Dial *62.**
Your phone plays a recorded message indicating the number of the parked call.
 - Step 3** Wait to hear the parking slot #.
 - Step 4** Press **Transfer** .
 - Step 5** (Optional) Communicate the parked number to the person retrieving the call.
-

Retrieve a Call on Hold with Call Park

You can pick up a parked call from anywhere in your network.

Before you begin

You need the number that was used to park the call.

Procedure

-
- Step 1** Lift the receiver and listen for dial tone.
 - Step 2** **Dial *66 + the parking spot** the call was placed in.
 - Step 3** You are now connected with the caller in that parking slot #.
-

Forward Calls

You can forward incoming calls from your phone to another number.

Enable Call Forward – All Calls

Procedure

-
- Step 1** Lift the receiver and listen for dial tone.
 - Step 2** Press *72 or Forward softkey.
 - Step 3** When prompted, enter your PIN.
 - Step 4** Press 1.
 - Step 5** When prompted, enter the destination phone number, starting with a 1, i.e. 1 800 555 1212.
-

Disable Call Forward – All Calls

Procedure

-
- Step 1** Lift the receiver and listen for dial tone.
 - Step 2** Press *72 or Forward softkey
 - Step 3** When prompted, enter your PIN.
 - Step 4** Press 2.
-



Note: Forwarding of all calls is available remotely using the voicemail system. This feature can be accessed remotely by dialing your phone number, and while listening to the voicemail greeting pressing

the # key. This will allow you to enter your PIN and access the voicemail system. In the Personal options menu (8), you can enable call forwarding.

Enable Call Forward – Busy

Procedure

- Step 1** Lift the receiver and listen for dial tone.
 - Step 2** Press *90.
 - Step 3** When prompted, enter your PIN.
 - Step 4** Press 1.
 - Step 5** When prompted, enter the destination phone number, starting with a 1, i.e. 1 800 555 1212.
-

Disable Call Forward – Busy

Procedure

- Step 1** Lift the receiver and listen for dial tone.
 - Step 2** Press *90.
 - Step 3** When prompted, enter your PIN.
 - Step 4** Press 2.
-

Enable Call Forward – No Answer

Procedure

- Step 1** Lift the receiver and listen for dial tone.
 - Step 2** Press *92.
 - Step 3** When prompted, enter your PIN.
 - Step 4** Press 1.
 - Step 5** When prompted, enter the destination phone number, starting with a 1, i.e. 1 800 555 1212.
-

Disable Call Forward – No Answer

Procedure

- Step 1** Lift the receiver and listen for dial tone.
 - Step 2** Press *92.
 - Step 3** When prompted, enter your PIN.
 - Step 4** Press 2.
-

Enable Call Forward – Out of Service

Procedure

- Step 1** Lift the receiver and listen for dial tone.
 - Step 2** Press *94.
 - Step 3** When prompted, enter your PIN.
 - Step 4** Press 1.
-

Step 5 When prompted, enter the destination phone number, starting with a 1, i.e. 1 800 555 1212.

Disable Call Forward – Out of Service

Procedure

- Step 1** Lift the receiver and listen for dial tone.
 - Step 2** Press *94.
 - Step 3** When prompted, enter your PIN.
 - Step 4** Press 2.
-

Remotely Access Call Forwarding for All Calls

Procedure

- Step 1** Access Your Voicemail Menu
 - **Dial your 10-digit phone number** from a phone not connected to your account.
 - When you hear your voicemail greeting, **press #**.
 - **Enter your 4-digit PIN**, followed by **#**.
 - Step 2** **Press 8** for personal options.
 - Step 3** **Press 5** to access the Call Forwarding Menu.
 - Step 4** Current Status of Call Forwarding feature will be given.
 - Step 5** To **forward** all calls, **press 1**.
 - Enter **forwarding destination number** followed by the # sign.
 - You will hear, “All calls will be forwarded”.
 - Step 6** To send all calls to your line, **press 2**.
 - You will hear, “Calls will ring your line, goodbye”.
-

Transfer Calls

You can transfer an active call to another person.

Call Transfer – Attended Transfer

When you transfer a call, you can stay on the original call until the other person answers. This gives you an opportunity to talk privately with the other person before you remove yourself from the call.

You can also swap between both callers to consult with them individually before you remove yourself from the call.

Before you begin

You have an active call that needs to be transferred.

Procedure

- Step 1** While on a call, press **Transfer**.
The caller will begin to hear hold music.
 - Step 2** **Dial** the extension/phone number where the call should be transferred.
 - Step 3** When the extension/phone number called picks up, inform them of the transfer.
 - Step 4** Press **Transfer** again.
-

NOTE: If you hang up before the calling party answers, your original caller will be on hold.

Call Transfer – Blind Transfer

If you are sending a call to another party and do not need to talk to them before transferring the call, use this method. The party you transfer the call to will see the call as if it is coming from the original caller.

Before you begin

You have an active call that needs to be transferred.

Procedure

Step 1 Press More  softkey

Step 2 Press **[Blind]**.

Step 3 Dial the extension/phone number where the call should be transferred.

Step 4 **Hang up**

- The caller will be transferred over to the new extension/phone number.
-

Call Transfer – Directly to Voicemail

When you want to transfer a current call to the correct person without interrupting their current call or having it ring at their desk, you can transfer the current call directly to that user's voicemail box.

Procedure

Step 1 Press **Transfer**.

Step 2 **Dial *00** + the extension.

Step 3 Press **Transfer**.

- The caller will be in the other user's voicemail box.
-

Conference Calls and Meetings

You can talk with several people in a single call. You can dial another person and add them to the call. If you have multiple phone lines, you can join two calls across two lines. The conference ends when all participants hang up.

Add Another Person to a Call

Procedure

Step 1 From an active call, press **Conference** .

Step 2 Enter the phone number for the party you want to add and press **Dial**.

Step 3 Press **Conference**.

The conference begins.

Page a Group of Phones (Multicast Paging)

Your administrator can configure your phone as a part of a paging group. In a paging group, your phone can automatically answer pages from other Multiplatform phones in the phone system. Each paging group has a unique number associated with it. Your administrator gives you the configured paging group numbers. When your phone is paged, you hear three short beeps. The phone establishes one-way audio between you and the phone that called you. You do not have to accept the page.

Procedure

Press the line key to start a Group Page.

Group Night Forwarding

Group Night Forwarding, also known as Night Mode, allows users in a group to forward group calls whenever by dialing star code 73.

When enabled, incoming calls to the group are redirected to a pre-set phone number, which can be to another group, a voicemail box, a user, or an off-net number (like the night manager's cell phone). And because it's controlled by star code 73, each group can manage it independently.

Shared Group Numbers

The group number does not have to be unique. When the same number is assigned to multiple groups, enabling/disabling Night Forwarding for one will enable/disable it for them all. This strategy is useful when multiple teams are on the same schedule, or one team is assigned to answer calls for multiple groups. However, to allow each group to manage their Night Forwarding setting independently, all auto-attendant groups must have a unique group number.

Enable or Disable Group Night Forwarding

Only a user assigned to the group can enable or disable Night Forwarding for that group. However, if multiple groups are assigned the same group number, the user who enables/disables it only has to belong to one of the groups.

A user in the auto-attendant group will dial the Group Forwarding star code 73 + the group number.

For example, the star code is 73 and the group number is 102, the user will dial *73102.

Follow the audio prompts:

Procedure

Step 1 Dial *73 + Group Number

Step 2 Press 1 to turn on Night Forwarding.

Step 3 Press 2 to turn off Night Forwarding.

Step 4 Press 3 to set the Night Forwarding number.

NOTE : Call Queuing : If calls are in the queue when Night Forwarding is enabled, those calls will remain in the queue until answered, and all new calls to the queue will be forwarded.

Multiple Lines

If you share phone numbers with other people, you could have multiple lines on your phone. When you have multiple lines, you have more calling features available to you.

Answer the Oldest Call First

You can answer the oldest call available on all your phone lines, including Hold Reversion and Park Reversion calls that are in an alerting state. Incoming calls always have priority over Held or Park Reversion calls.

When working with multiple lines, you typically press the line button for the incoming call you want to answer. If you just want to answer the oldest call regardless of line, press **Answer**.

View All Calls on Your Phone

You can view a list of all your active calls—from all your phone lines—sorted in chronological order, oldest to newest.

The list of all calls is useful if you have multiple lines or if you share lines with other users. The list displays all your calls together.

Shared Lines

You can share a single phone number with one or more of your coworkers. For example, as an administrative assistant, you might be responsible for screening calls for the person that you support.

When you share a phone number, you can use that phone line just like you would any other line, but you should be aware of these special characteristics about shared lines:

- The shared phone number appears on all phones that share the number.
- If your coworker answers the call, the shared line button and the session button are solid red on your phone.
- If you put a call on hold, your line button is solid red and the session button pulses red. Your coworker's line button is also solid red and the session button pulses red.

CHAPTER 3


Contacts

Corporate Directory

You can look up a coworker's number from your phone, which makes it easier to give them a call. Your administrator sets up and maintains the directory.


Dial a Contact in the Corporate Directory

Procedure

- Step 1** Press **Contacts** .
 - Step 2** Select the directory name that you have defined.
 - Step 3** Select a search criteria.
 - Step 4** Enter your search criteria and press **Submit**.
 - Step 5** Select the contact and press **Dial**.
-


Add a New Contact to Your Personal Address Book

Procedure

- Step 1** Press **Contacts** .
 - Step 2** Select **Personal Address Book**.
 - Step 3** Press **Add** or you can press the **Select** button.
 - Step 4** Enter a name and at least one phone number.
 - Step 5** Select a custom ringtone for the contact.
 - Step 6** Press **Save** to add the entry to your personal directory.
-


Search for a Contact in Your Personal Address Book

Procedure

- Step 1** Press **Contacts** .
 - Step 2** Select **Personal Address Book**.
 - Step 3** Select **Option > Search**.
 - Step 4** Enter the address entry to search for, and press **Submit**.
You can only search by name (case insensitive). Search by number is not supported.
-


Call a Contact in Your Personal Address Book

Procedure

- Step 1** Press **Contacts** .
 - Step 2** Select **Personal Address Book** and search for an entry.
 - Step 3** Select the personal address book entry that you want to dial.
 - Step 4** Press **Call**.
-


Edit a Contact in Your Personal Address Book

Procedure

-
- Step 1** Press **Contacts** .
 - Step 2** Select **Personal Address Book** and search for an entry.
 - Step 3** Select the entry you want to change.
 - Step 4** Modify the entry information.
 - Step 5** Press **Save** to modify a phone number.

Remove a Contact from Your Personal Address Book

Procedure

-
- Step 1** Press **Contacts** .
 - Step 2** Select **Personal Address Book**.
 - Step 3** Select **Search address entry**.
 - Step 4** Select the address entry and press **Option** > **Delete** to delete the entry.
-

Speed-Dial Numbers

When you dial a number on your phone, you enter a series of digits. When you set up a speed-dial number, the speed-dial number must contain all the digits you need to make the call. For example, if you need to dial 9 to get an outside line, you enter the number 9 and then the number you want to dial.

You can also add other dialed digits to the number. Examples of additional digits include a meeting access code, an extension, a voicemail password, an authorization code, and a billing code. The dial string can contain the following characters:

- 0 to 9
- Pound (#)
- Asterisk (*)
- Comma (,)—This is the pause character, and gives a 2-second delay in the dialing. You can have several commas in a row. For example, two commas (,,) represent a pause of 4 seconds. The rules for dial strings are:
 - Use the comma to separate the parts of the dial string.
 - An authorization code must always precede a billing code in the speed-dial string.
 - A single comma is required between the authorization code and the billing code in the string.
 - A speed-dial label is required for speed dials with authorization codes and additional digits.

Before you configure the speed dial, try to dial the digits manually at least once to ensure that the digit sequence is correct.



Note: *Your phone does not save the authorization code, billing code, or extra digits from the speed dial in the call history. If you press **Redial** after you connect to a speed-dial destination, the phone prompts you to enter any required authorization code, billing code, or additional digits manually.*

Example

To set up a speed-dial number to call a person at a specific extension, and if you need an authorization code and billing code, consider the following requirements:

- You need to dial **9** for an outside line.
- You want to call **5556543**.
- You need to input the authorization code **1234**.
- You need to input the billing code **9876**.
- You must wait for 4 seconds.
- After the call connects, you must dial the extension **56789#**.

In this scenario, the speed-dial number is **95556543,1234,9876,,56789#**.

CHAPTER 4

Recent Calls

Recent Calls List

Use the Recents list to see the 180 most recent individual calls and call groups.

If your Recents list reaches the maximum size, the next new entry overwrites the oldest entry in the list.

If you have missed calls, the phone shows the number of missed calls for the line on the main screen (up to 99 missed calls). To clear the number from the line, you view your Recents list.

The missed calls number that displays on the main screen may differ from the actual number of calls in the missed calls list. Some missed calls may have been removed from the list by the phone because you have more than 180 entries in the Recents list.

View Your Recent Calls

Check to see who's called you recently.



Note: Each line has missed call badging. You can view the number of missed calls per line on the phone screen. The maximum missed call badge is 99. When you view either the All calls or Missed calls list on the phone screen for a particular line, the missed call badge for the selected line gets cleared. The missed call badge and the actual number of missed calls may be different due to a display limit of 180 calls for the Recents list. This limit consists of outgoing calls, missed calls, and incoming calls. Also, there can be some old missed calls that get added to the count for the missed call badge. This can get overwritten in the Recents list.

Procedure

Step 1 Select a line to view.

Step 2 Press **Applications** .

Step 3 Select **Recents**.

Step 4 Choose to view all recent calls, or to view a certain kind of recent call.

- All Calls
- Missed Calls
- Received Calls
- Placed Calls

Step 5 Press **Select**.

Return a Recent Call


If you want to call back the last person that called you, instead of dialling their number, you can use Call Return.

Use Call Return

Procedure


- Step 1** Lift the receiver.
 - Step 2** Dial ***69**.
 - Step 3** You will be connected to the last number that called you.
-

Procedure

- Step 1** Press **Applications** .
 - Step 2** Select **Recents**.
 - Step 3** Select the call record that you want to dial.
 - Step 4** (Optional) Press **Edit call** to edit the call record.
 - Step 5** Press **Call**.
-

Clear the Recent Calls List

Procedure

- Step 1** Select a line to view.
 - Step 2** Press **Applications** .
 - Step 3** Select **Recents**.
 - Step 4** Choose to view all recent calls, or to view a certain kind of recent call.
 - All Calls
 - Missed Calls
 - Received Calls
 - Placed Calls
 - Step 5** Press **Select**.
 - Step 6** Press **Delete list**.
 - Step 7** Press **Delete**.
-


Create a Contact From a Recents Record

Procedure

- Step 1** Display a Recents record.
 - Step 2** Press **Options**.
 - Step 3** Press **Add to address book**.
-

Delete a Call Record


Procedure

- Step 1** Press **Applications** .
- Step 2** Select **Recents**.
- Step 3** Choose to view all recent calls, or to view a certain kind of recent call.
- All Calls
 - Missed Calls
 - Received Calls
 - Placed Calls
- Step 4** Press **Select**.
- Step 5** Highlight the individual record or call group that you want to delete.
- Step 6** Press **Delete entry**.
- Step 7** Press **Delete** again to confirm.
- Step 8** Press **Back**.
-

Delete All Call Records

You can delete all call history records on your phone.

Procedure


- Step 1** Press **Applications** .
- Step 2** Select **Recents**.
- Step 3** Press **Recents**.
- Step 4** Select **Option > delete All**.
- Step 5** Press **Delete** again to confirm.

CHAPTER 5

Voicemail

Your Voicemail Account

You can access your voice messages directly from your phone. But your administrator must set up your voicemail account, and may also set up your phone to access the voicemail system.

The **Messages**  button on your phone acts as a speed dial into the voicemail system.

When you aren't at your desk, you can call your voicemail system to access your voicemail. Your administrator can give you the voicemail system phone number.

Check for New Voice Messages

To find out if you have new voicemail messages, look for one of these signs:

- The light strip on your handset is solid red.
- The number of missed calls and voicemail messages is displayed on your screen. If you have more than 99 new messages, a plus (+) sign is displayed.
- An exclamation mark (!) indicates urgent voicemail messages.

You will also hear a stutter tone played from your handset, headset, or speakerphone when you use a phone line. This stutter tone is line-specific. You only hear it when you use a line that has voice messages.

Access Voicemail (Your Phone)

Procedure

- Step 1** Press **Messages** .
- Step 2** Follow the voice prompts.

Access Voicemail (Another Phone)


Procedure

- Step 1** Dial *98 from the phone that is connected to your account.
- Step 2** Enter your 4-digit PIN, followed by #.
 - Your default PIN is 1234.
- Step 3** Follow the voice prompts.

Access Voicemail Remotely

Procedure

- Step 1** Dial your 10-digit phone number from a phone not connected to your account.
- Step 2** When you hear your voicemail greeting, press #.
- Step 3** Follow the voice prompts.




CHAPTER 6

Settings

Settings Overview

You can customize your phone in a number of ways:

- From the menus on the phone, accessed from the **Applications**  button. The common settings menus are:
 - User preferences
 - Device administration

User Preferences Menu

You can customize many settings for your phone from the **User preferences** menu. The menu groups settings according to functions.


Call Preferences

The **User preferences > Call preferences** menu allows you to set the way your phone handles calls.

Control the Call Waiting Tone



When you are talking with someone and get another call, you can set the phone to give a call waiting tone.

Procedure

- Step 1** Press **Applications** .
- Step 2** Select **User preferences > Call preferences > Call waiting**.
- Step 3** Press **On** if you want the call waiting tone, or press **Off** if you don't want the call waiting tone.
- Step 4** Select **Set** to apply the changes.


Set Up an Auto Answer Page

Procedure

- Step 1** Press **Applications** .
- Step 2** Select **User preferences > Call preference > Auto answer page**.
- Step 3** Press **On** to enable the Auto answer page or press **Off** to disable Auto answer page.
- Step 4** Press **Set** to save the changes.
- Step 5** Press  to exit.

Enable the Missed Call Shortcut

Procedure

- Step 1** Press **Applications** .
- Step 2** Select **User preferences > Call preferences > Missed call shortcut**.
- Step 3** Press **On** if you want to the shortcut, or press **Off** if you don't want the shortcut.
- Step 4** Select **Set** to apply the changes.


Audio Preferences

The **User preferences > Audio preferences** menu allows you to customize ringtones and how you prefer to answer calls.

Set Your Preferred Audio Device


You can set how you want to answer the call: headset, speaker, or handset.

Procedure

-
- Step 1** Press **Applications** .
 - Step 2** Select **User preferences > Audio preferences > Preferred audio device**.
 - Step 3** Press **Select** to scroll through the list of devices.
 - Step 4** Press **Set** to save the selection.
 - Step 5** Press **Back** to exit.

Change the Ringtone

Procedure

-
- Step 1** Press **Applications** .
 - Step 2** Select **User preferences > Audio preferences > Ext (n) - Ring tone**, where n= extension number.
 - Step 3** Scroll through the list of ringtones and press **Play** to hear a sample.
 - Step 4** Press **Select** softkey and then **Set** softkey to save a selection.
 - Step 5** Press **Back** to exit.


Screen Preferences

The **User preferences > Screen preferences** menu allows you to set your phone screen display options.

Change the Screen Saver

You can enable your phone screen saver, and specify its appearance and the amount of time for the phone to be idle before the screen saver appears.


Procedure

-
- Step 1** Press **Applications** .
 - Step 2** Select **User preferences > Screen preferences > Screen saver**.
 - Step 3** Select **On** to enable the screen saver, or press **Off** to turn the screen saver off.
 - Step 4** Select **Screen saver settings** to choose the settings:
 - **Screen saver type**—Choose one of the following options:
 - **Clock**—Displays a rounded clock with the wallpaper in the background.
 - **Download Picture**—Displays a picture pushed from the phone web page.
 - **Logo**: Displays a logo as the phone screensaver. This image is added in the Logo URL field of the phone web page.
 - **Lock**—Displays a lock icon on the phone screen.
 - **Trigger interval**—Enter the number of seconds that the phone remains idle before the screen saver turns on.
 - **Refresh interval**—Enter the number of seconds before the screen saver should refresh (if, for example, you chose a rotation of pictures).
 - Step 5** Press **Set**.

Set the Backlight Timer


You can adjust the length of time that the phone screen is bright before it automatically dims.

Procedure

- Step 1** Press **Applications** .
- Step 2** Select **User preferences > Screen preferences > Backlight timer**.
- Step 3** Press **Select** to scroll through the list and select a duration for which the backlight remains on:
- 10 seconds
 - 20 seconds
 - 30 seconds
 - Always On
 - Off
- Step 4** Press **Set** to apply the selection.
-

Adjust the Phone Screen Contrast

Procedure


- Step 1** Press **Applications** .
- Step 2** Select **User preferences > Screen preferences > Contrast level**.
- Step 3** Press the Navigation cluster up or down to increase or decrease the brightness.
- Step 4** Press **Save**.
-

Attendant Console Preferences

The **User preferences > Attendant console preferences** menu allows you to customize how calls display.

Change the Display Mode

Procedure

- Step 1** Press **Applications** .
- Step 2** Select **User preferences > Attendant console preferences > Display mode**.
The following options are available:
- **Name**
 - **Ext**
 - **Both**
- Step 3** Choose the display mode and press **Set**.
-


Device Administration Settings

You can set some other preferences from the phone in the **Device administration** menu.

Change the Time Format

You can change the current time format that the phone screen displays.


Procedure

- Step 1** Press **Applications** .
 - Step 2** Select **Device administration > Date/Time > Time format**.
To set daylight savings, select **Device administration > Date/Time > Daylight Savings**. Press **On** to turn on the daylight savings and press **Off** to turn it off.
 - Step 3** (Optional) Select **Device administration > Date/Time > Time Zone**.
 - Step 4** Select a time format and press **Set** to apply the changes.
 - Step 5** Press to exit.
-

Change the Date Format

You can change the date format that you want to see on your phone screen.


Procedure

- Step 1** Press **Applications** .
 - Step 2** Select **Device administration > Date/Time > Date format**.
 - Step 3** Select a date format and press **Set** to apply the changes.
 - Step 4** Press to exit.
-

Set Language

Depending upon how your phone is configured, you may be able to change the language used by your phone.

Procedure


- Step 1** Press **Applications** .
 - Step 2** Select **Device administration > Language**.
 - Step 3** Select a language from the list of available languages.
 - Step 4** Select **Save**.
-

Set up Power Save

You can put your phone into power save mode when your phone is idle. If your phone is not idle, you can't turn power save on and you see a message on the screen.

When your phone is in power save mode, the screen is not lit and the **Select** button is lit. You press the **Select** button to wake up the phone.

Procedure

- Step 1** Press **Applications** .
 - Step 2** Select **Device administration > Power save**.
 - Step 3** Select **OK**.
-

Restart Your Phone

You may have to reboot your phone for a software upgrade or other changes to take effect. Your settings or other customizations do not change.

Procedure

- Step 1** Press **Applications** .
 - Step 2** Select **Device administration > Restart**.
 - Step 3** Select **OK** to confirm that you want to reboot your phone.
-